



Installation Guide

Contents

Copyright Information	3
Installing Mac Fax.....	4
Help using Mac Fax	7

Copyright Information

Trademarks

- Mac OS X, OS X, Gatekeeper and the brand names and other product names of other Apple products are trademarks of Apple Corporation in the United States and/or other countries.
- All other product names and logos are trade and service marks of their respective companies.

Copyright

Mac Fax is copyright © 2013 Toshiba (Australia) Pty Ltd. All rights reserved.

The information contained in this document is the property of Toshiba (Australia) Pty Ltd.

Neither receipt nor possession hereof confers or transfers any right to reproduce or disclose whole or any part of the contents hereof, without the prior written consent of Toshiba (Australia) Pty Ltd.

Disclaimer

The following notice sets out the exclusions and limitations of liability of Toshiba (Australia) Pty Ltd (including its employees, agents and sub-contractors) to any purchaser or user ('User') of the Mac Fax, including its accessories, options and bundled software ('Product').

1. The exclusion and limitations of liability referred to in this notice shall be effective to the fullest extent permissible at law. For the avoidance of doubt, nothing in this notice shall be taken to exclude or limit Toshiba (Australia) Pty Ltd's liability for death or personal injury caused by Toshiba (Australia) Pty Ltd's negligence or Toshiba (Australia) Pty Ltd's fraudulent misrepresentation.
2. All warranties, conditions and other terms implied by law are, to the fullest extent permitted by law, excluded and no such implied warranties are given or apply in relation to the Products.
3. Toshiba (Australia) Pty Ltd shall not be liable for any loss, cost, expense, claim or dam-age whatsoever caused by any of the following:
 - a. use or handling of the Product otherwise than in accordance with the manuals, including but not limited to Operator's Manual, User's Guide, and/or incorrect or careless handling or use of the Product;
 - b. any cause which prevents the Product from operating or functioning correctly which arises from or is attributable to either acts, omissions, events or accidents beyond the reasonable control of Toshiba (Australia) Pty Ltd including without limitation acts of God, war, riot, civil commotion, malicious or deliberate damage, fire, flood, or storm, natural calamity, earthquakes, abnormal voltage or other disasters;
 - c. additions, modifications, disassembly, transportation, or repairs by any person other than service technicians authorized by Toshiba (Australia) Pty Ltd; or
 - d. use of paper, supplies or parts other than those recommended by Toshiba (Australia) Pty Ltd.
4. Subject to paragraph 1, Toshiba (Australia) Pty Ltd shall not be liable to Customer for:
 - a. loss of profits; loss of sales or turnover; loss of or damage to reputation; loss of production; loss of anticipated savings; loss of goodwill or business opportunities; loss of customers; loss of, or loss of use of, any software or data; loss under or in relation to any contract; or
 - b. any special, incidental, consequential or indirect loss or damage, costs, expenses, financial loss or claims for consequential compensation;

whatsoever and howsoever caused which arise out of or in connection with the Product or the use or handling of the Product even if Toshiba (Australia) Pty Ltd is advised of the possibility of such damages.

Toshiba (Australia) Pty Ltd shall not be liable for any loss, cost, expense, claim or dam-age caused by any inability to use (including, but not limited to failure, malfunction, hang-up, virus infection or other problems) which arises from use of the Product with hardware, goods or software which Toshiba (Australia) Pty Ltd has not directly or indirectly supplied

Installing Mac Fax

Requirements

Mac Fax is supported on the following operating systems (both PowerPC and Intel where applicable):

- Mac OS X 10.4 (Tiger)
- Mac OS X 10.5 (Leopard)
- Mac OS X 10.6 (Snow Leopard)
- Mac OS X 10.7 (Lion)
- OS X 10.8 (Mountain Lion)

Mac Fax also has the following system requirements:

- 512 MB RAM or more
- 2 MB of free disk space for installation
- Screen resolution of at least 800x600 or greater

Choosing an Installer

There are two installers available for Mac Fax – **X4** and **X7**. The X4 installer should be used when installing on Mac OS X 10.4, Mac OS X 10.5 and Mac OS X 10.6 platforms. For Mac OS X 10.7 or newer, the **X7** installer should be used instead.

Gatekeeper is a feature of Mac OS X 10.7 (and later) which prevents the installation of any downloaded software which is not digitally signed, and also prevents the installation of downloaded software that has been tampered with. Digitally signed installation packages are not compatible with Mac OS X 10.4, so two separate installers are required for Mac Fax to support both earlier versions of Mac OS X and the latest version.

Installation Procedure


1. Double-click on the Mac Fax X7 or Mac Fax X4 icon.




2. At the Installer Welcome screen, click “Continue”:




- At the following screen, read through the license agreement of the software. After reading the license agreement, click “Continue”:



- If you agree with the terms and conditions of the license agreement, click “Agree”. If you disagree, click “Disagree” to exit the installation (you will not be able to use Mac Fax).




- At the following screen, click “Install”. You will be prompted to enter the username and password of an account with administrative privileges.



- The installer will begin unpacking and installing Mac Fax.



- After the installer has finished installing Mac Fax, click "Close" to close the installer.



Help using Mac Fax

Mac Fax installs into your Applications directory. For further help on using Mac Fax, refer to the Mac Fax User Guide which is accessible from the Mac Fax application itself.

1. Navigate to the “Applications” folder and locate “Mac Fax”:



2. Double-click “Mac Fax” to open it. **N.B. no application windows will appear**, however the menu bar at the top of the screen will change to show that Mac Fax is the active application.
3. Under the “Help” menu in the menu bar, click “Mac Fax Help”

